

Guide to Assembly & Usage

Professional Workbench

Information

If in doubt, contact the supplier

Please read these instructions thoroughly before commencing assembly & retain a copy for your reference

Inspect all packages for damage and check that all components ordered are included

Assembly should be undertaken by at least two competent people

Tools required – Screw driver, 10mm spanner, drill, drill bits

Caution

During assembly:

Take care when handling heavy items, particularly when lifting or stretching

Wear appropriate safety clothing - protective gloves and footwear are recommended

Build on a suitable level floor surface, which is strong enough to support the load

Allow adequate working space and be aware of others working around you

Dispose of packaging materials responsibly

Warning

Rules for safe use of workbenches:

Please retain these Instructions for reference and ensure that users understand the rules for safe use

NEVER CLIMB ON THE WORKBENCH

THIS PRODUCT IS DESIGNED FOR HAND LOADING ONLY

DO NOT USE IN DAMP OR WET ENVIRONMENTS

ENSURE THAT THE MAXIMUM LOAD CARRYING CAPACITIES ARE NOT EXCEEDED

PLEASE REFER TO THE LOADING CHART SUPPLIED FOR DETAILS

Workbenches are safe when used responsibly.
If in doubt, contact the supplier



*UDL = Uniformly Distributed Load

COMPONENT CHECK LIST

Component	Quantity
Left Hand Upright	1
Right Hand Upright	1
Top Frame	1
Shelf	1
Back Plate	1
Ply Top	1
Feet	4
M8 Bolt	12
20mm Screw	6
30mm Screw	4

*Add 1 for PRS1 or add 2 for PRS2

If you have any missing components please take note of the part name and contact your supplier

Assembly - Professional Workbench


1 Start by fitting the plastic feet into the bottom of the uprights



2 Then slide one of the uprights into the top frame with the nut inserts facing outwards



3 Fit and tighten x2 bolts between the uprights and top frame using a 10mm spanner



4 Repeat stage 2 & 3 with the other upright




5 Fit the shelf between the uprights and secure using x8 bolts




6 Place the ply top on the floor with the cleanest side facing down. On top of this place the frame work




7 Adjust the frame to have a distance of 110mm from the front edge to the front of the frame



8 And 18mm from the two outside edges



9 At the 6 pre-drilled holes in the frame, drill guide holes in the ply top and fit the 20mm screws



10 Align and drill guide holes for the back plate. Fit using x4 30mm screws



Note: Illustrations not to scale

The information contained in this leaflet was accepted as correct at the date of publication. However, the manufacturer reserves the right to make any necessary changes, in line with the product development and improvement. Although all reasonable care has been taken to make it as complete and accurate as possible, no liability can be accepted for any inaccuracies or omissions.

Loading information

Shelf load capacities

Maximum permitted shelf capacities are based on uniformly distributed loads (UDL). Please note that the above bench capacity may limit the maximum load per shelf:

Shelf	kg UDL
Bench Top	350
Lower Shelf	50

IF YOU ARE IN ANY DOUBT REGARDING LOAD CAPACITIES, PLEASE CONTACT YOUR SUPPLIER