
Guide to Assembly & Usage

BiG800 Mobile Packing Bench











If you have any missing components please take note of the part name and contact your supplier

Assembly – BiG800 Mobile Packing Bench











Slot two long front and back beams G 5 into a side frame at the same height as lower side beam. Knock into place with a rubber mallet.











8









Assembly – BiG800 Mobile Packing Bench





Loading information

BiG800 Mobile Packing Bench

These load charts relate to bench layouts with the following specifications:

- Maximum upright height = 950mm Similar distances (height) between levels
- Benches are positioned on a level floor

For any other uses, please refer to your supplier for detailed loading capacities

Packing Bench load capacities

Maximum permitted shelf capacities are based on UDL[†]. Please note that the bench capacity may limit the maximum load per shelf:

	BiG800 Mobile Packing Bench
Maximum load per bench	Load Capacity per shelf
Up to 950mm high	100kg

IF YOU ARE IN ANY DOUBT REGARDING LOAD CAPACITIES, PLEASE CONTACT YOUR SUPPLIER

 $^{\dagger}\text{UDL} = \text{Uniformly Distributed Load}$