Guide to Assembly & Usage

4 Level Workstation



Information

If in doubt, contact the supplier



Read this guide thoroughly before commencing assembly and retain for future reference



Before commencing assembly, unpack carefully and check that all components ordered are included



Assembly should be undertaken by a minimum of two competent people



Tools - Small rubber mallet



Assess for floor fixing. Tall narrow bays may require this to ensure stability



Caution

During assembly, ensure to:



Take care during assembly and in use, particularly when lifting or stretching & when using tools



Wear appropriate safety clothing protective gloves and footwear are recommended



Build on a suitable level floor, which is strong enough to support the load and allow adequate working space



Dispose of packaging materials responsibly



Warning

Rules for the safe use of Workstations:



Ensure these instructions are retained for reference and that users are aware of the rules for safe use



Never climb on the structure or stand on the Workstation



Do not lean or support ladders, steps, or other objects against Workstation



Always use safety steps to reach high shelves



Do not use in damp or wet conditions



Load heavy items on the lower shelves & lighter items on the higher



This product is designed for hand loading only



Ensure that the maximum load carrying capacities are not exceeded



Please refer to the loading information supplied for details

Workstations are safe when used responsibly. If in doubt, contact the supplier



| COMPONENT CHEC | CK LIST | WSA | WSB |
|--------------------|---|----------|----------|
| Component | | Quantity | Quantity |
| ♠ Tall Uprights | A. V. | 2 | 2 |
| Medium Uprights | | 2 | 4 |
| G Short Uprights | 14.14.14.14.14.14.14.14.14.14.14. | 2 | N/A |
| Chipboard for Bend | ch | 2 | 2 |
| Chipboard for Sh | elf | 2 | 2 |
| Plastic Feet | | 6 | 6 |
| G Front/Back Beam | | 8 | 8 |
| 1 Side Beam | U U | 4 | 4 |
| Shelf Side Beam | Ų Ų | 4 | 4 |
| Centre Support | | 2 | 4 |
| Shelf Centre Sup | port | 2 | 4 |
| | | 1 | |

Loading information

Medium Duty Adjustable Workbench

For any other layouts, please refer to your supplier for detailed loading capacities

| Maximum load per top shelf | Medium Duty Adjustable Workbench Maximum load per bench level |
|----------------------------|--|
| 100kg | 300kg |

Shelf load capacities

Maximum permitted bay capacities are based on UDL+.

IF YOU ARE IN ANY DOUBT REGARDING LOAD CAPACITIES, PLEASE CONTACT YOUR SUPPLIER †UDL = Uniformly Distributed Load

If you have any missing components please take note of the part name and code and contact your supplier

Assembly - 4 Level Workstation























